

		Alarm Signalling*	Keyswitch Arm/Disarm	Keypus interactive	Program Panel User	UDL
HONEYWELL	FA 147C/148C(Vista 15)	☑	-	-	-	-
	FA 162	☑	-	-	-	-
	Vista 10PSIA	☑	☑	-	-	-
	Vista 10SE	☑	-	-	-	-
	Vista 15P/20P	☑	☑	☑	☑	☑
	Vista 15SE	☑	☑	-	-	-
	Vista 15/20PSIA	☑	☑	☑	☑	☑
	Vista 20SE	☑	-	-	-	-
	Vista 21IP	☑	☑	☑	☑	☑
	Vista 32FB/128FBP	☑	☑	☑	☑	-
	Vista 50P	☑	☑	☑	☑	-
	Vista 128BP	☑	☑	☑	☑	-
	Vista 128SIA	☑	☑	☑	-	-
DSC	ALEXOR	☑	☑	-	-	☑
	IMPASSA	☑	☑	-	-	☑
	NEO	☑	☑	-	-	☑
	PC 585	☑	☑	☑	-	☑
	PC1616/1832/1864	☑	☑	☑	☑	☑
	PC 4020 MAXSYS	☑	☑	-	-	-
	Power832 PC5010**	☑	☑	☑	-	-
	Power864 PC5020	☑	☑	☑	-	☑
	SCW 9045/9047	☑	☑	-	-	-
Interlogix	Concord 4	☑	☑	-	-	-
	Concord Express	☑	☑	-	-	-
	NX 4/4V2	☑	☑	☑	☑	☑
	NX 6/6V2	☑	☑	☑	☑	☑
	NX 8/8V2	☑	☑	☑	☑	☑
	NX 8E	☑	☑	☑	☑	☑
	Simon XT	☑	-	-	-	-
NAPCO	GEM-P1632	☑	☑	☑	-	-
	GEM-P1664	☑	☑	☑	☑	-
	GEM-P3200	☑	☑	☑	-	-
	GEM-P9600	☑	-	☑	-	-
	GEM-P816	☑	☑	☑	-	-
PARADOX	Digiplex EVO 192	☑	☑	-	-	-
	Digiplex EVO HD	☑	☑	-	-	-
	SP728/738	☑	☑	-	-	-
	SP1738	☑	☑	-	-	-
	SP4000	☑	☑	-	-	-
	SP5500	☑	☑	-	-	-
DMP	XR 20/40/XR SUPER6	☑	☑	-	-	-
	XR 150	☑	☑	-	-	-
	XT 30D/50DN	☑	☑	-	-	-
i.a.	ELK-M1	☑	☑	-	-	-

NOTE 1

- Keyswitch Arm/Disarm allows Away Arm of a single partition.
- Keybus integration allows Away and Stay Arm of multiple partitions, zone status and zone bypass.

NOTE 2

UDL feature (Upload/Download via RING/TIP) requires the use of additional 5530UDM extension module

*The Uplink Communicators with Dial-Capture interface support ContactID, SIA and Pulse 4+2 communication formats.

**Contact ID is manually programmed for DSC Power832/PC5010.