





CONTENTS

| GETTING STARTED | 3 |
|----------------------------------|----|
| DOWNLOAD THE SECURESMART APP | 3 |
| LOGIN | 3 |
| DASHBOARD | 4 |
| MENU | 5 |
| SETTING UP TOUCH ID | 6 |
| USING THE APPLICATION | 7 |
| SECURITY SYSTEM KEYPAD | 7 |
| HOME AUTOMATION | 8 |
| VIEWING LIVE VIDEO | 8 |
| DOOR LOCKS | 9 |
| LIGHTS & SWITCHES | 9 |
| THERMOSTATS | 10 |
| GARAGE DOORS | 10 |
| Z-WAVE DEVICES | 11 |
| EDITING Z-WAVE DEVICES | 11 |
| ADDING Z-WAVE DEVICES | 12 |
| REMOVING Z-WAVE DEVICES | 13 |
| REFRESHING Z-WAVE DEVICES | 14 |
| GETTING HELP | 14 |

GETTING STARTED

Welcome to the new SecureSmart application! With this application, you will be able to gain total control over your home by having access to your Security System, Lights, Locks, Thermostats, Cameras and Garage Doors.

DOWNLOAD THE SECURESMART APP

The free iOS SecureSmart app by ipDatatel, LLC, is downloadable from the App Store for Apple devices.



| Username | | |
|----------|-------|--|
| Password | | |
| | Login | |

LOGIN

Your local alarm dealer should have created a username and password for you to log into the application. If not, please contact your alarm dealer for this information. Every time the application is launched, it will check to see if any changes have been made to your account.

Once installed, enter your Username and Password provided by your alarm dealer.

DASHBOARD

The Dashboard is where you can easily access all of your devices attached to your account. It may take a few moments to poll all Z-Wave & Security devices to get the proper status.

| ●●○○ Verizor | n 🗢 4:31 PM | ≁ ७¥ ■ D | ●●○○ Verizor | n ᅙ 4:31 PM | ≁ ७ \$ ∎⊡ |
|--------------|---------------------------|-----------------|--------------|---------------------|--------------|
| = | Home | | = | Home | |
| Security | v Systems | | | | |
| ᢙ | Home Disarmed | > | | Patio Locked | |
| ^ | | | Lights | | |
| ð | Vacation Armed | > | -̈̈́́\ | Living Room | |
| Camera | S | | | | |
| 0 | Front Door | > | Ø | Study Off | \bigcirc , |
| | | | | | |
| \bigcirc | Patio | > | Thermo | stats | |
| Locks | | | \$ | DownStairs | 72.0°> |
| | Front Door Locked | | Ŀ | Upstairs | 76.0°> |
| \bigcirc | Patio | | Garage | Doors | |
| Lights | Locked | | | Garage Home Open | > |
| | 💲 SECURE <mark>S</mark> M | IART" | | SECURES SECURES | MART |

MENU

This can be accessed by pressing the Menu icon on the top left of the application (



LOCATIONS

Allows you to easily toggle between different monitored systems. To close the menu, simply swipe to the left.

| ●●○○ Verizon 🗢 | 4:32 PM | | 1 © \$ ■D |
|-----------------|---------|----------|-------------------|
| LOCATIONS | ŝ | ≡ | |
| Home | | Securit | y Systems |
| FEATURES | | \wedge | Home |
| Security System | | 10 | Disarmed |
| Locks | | \wedge | Vacatio |
| Garage Doors | | Ŀ | Armed |
| Lights | | Cameras | |
| Thermostats | | 0 | Front D |
| Cameras | | | |
| | | 0 | Patio |
| Video Accounts | | Locks | |
| Touch ID | | LUCKS | |
| OTHER | | | Front D Locked |
| About This App | | | |
| Privacy & Terms | | | Patio Locked |
| Log Out | | Lights | |
| | | | |
| SECURESMART | | | |

FEATURES

Selecting any category will display all connected and available devices.

Security System – View all security system(s). Locks – View all lock(s). Garage Doors – View all garage door opener(s). Lights – View all light(s). Thermostats – View all thermostat(s). Cameras – View all camera(s).

SETTINGS

Video Accounts – Enter cloud based video account. (For Secure-i accounts only). **Touch ID** – Set up Touch ID to arm and disarm your alarm system via fingerprint.

OTHER

About This App – This is where you will find the Bundle ID, version, revision, build date, and licenses. **Privacy & Terms** – Read Privacy & Terms.

LOG OUT Log out of the application.

SETTING UP TOUCH ID

You can easily arm and disarm your security system by simply using the fingerprint sensor on your iPhone. You no longer need to enter your four-digit security code!

| Ξ | Touch ID | |
|-----------------|----------|--|
| Security System | s | |
| Home | | |

To do this, simply select Touch ID from the menu under Settings, and then turn it on by sliding the button to the right.

Next, you will see a message prompting you to place your finger on the iPhone sensor. You will then be asked to enter your four-digit security code once and then once again to ensure the code is correct.

| ●●●○○ AT&T 夺 | 1:25 PM | ≁ % ■>+ | •••• AT |
|---------------|-------------------------|-----------------|---------|
| 〈 Home | Home | Û | < Hon |
| Ent | er your alarm | code | |
| | | | |
| 1 | 2 | 3 | |
| 4 | 5 | 6 | |
| 7 | 8 | 9 | |
| | 0 | Cancel | Touc |
| \$ | SECURE <mark>S</mark> M | ART | |


| •••∘∘ AT&T 奈 ✔ Home | 1:25 PM Home | ≁ * == >+ | |
|------------------------|--------------------------|----------------------|--|
| | IED ****AW/ ALL SECUR | | |
| 1 | 2 | 3 | |
| 4 | 5 | 6 | |
| 7 | 8 | 9 | |
| * | 0 | # | |
| Touch ID | Disarm | | |
| \$ | SECURE SMART | | |

USING THE APPLICATION

SECURITY SYSTEM KEYPAD

This is where you will be able to access your security system and use the Virtual Keypad as if you were standing in front of the keypad in your home. Simply enter your security code to arm or disarm your system.

Your keypad will look like one of these three main supported panels for GE, DSC, or Honeywell.



| •०००० Verizon 중 ✔ home | 8:10 PM Events | • 1 🗖 C |
|-------------------------------|-------------------|------------|
| Entry Exit Yesterday, 7:42 | AM | > |
| System Ar Aug 19, 2015, 9 | | > |
| Opening/D Aug 19, 2015, 4 | | > |
| Closed/Arr Aug 19, 2015, 1 | | > |
| System Dis | sarmed | > |

VIEWING SECURITY EVENTS

To View Events for any panel, you can access the event log by pressing () to see past signals transmitted from your security system.

HOME AUTOMATION

The security system is just the start of what SecureSmart has to offer. You can also control your Z-Wave products and cameras (locks, garage doors, lights, thermostats and cameras) all from the same application.

VIEWING LIVE VIDEO


You can view live video from IP cameras by selecting your camera from the dashboard screen.





DOOR LOCKS

This is where you will be able to access your door locks. You can check their status and toggle them to be locked or unlocked by using the switch or tapping the icon.






LIGHTS & SWITCHES

This is where you will be able to access any lightbulbs or switches. You can turn them on or off by toggling the switch or tapping the icon. Or, you can dim the light using the slider.

THERMOSTATS

This is where you will be able to access the thermostats you have connected to your gateway. You will be able to adjust the temperature, turn the fan on or off, and control whether it is heating or cooling.





GARAGE DOORS

This is where you will be able to control your garage door. You will be able to see its status as well as open and close the garage door. This feature only works with supported Z-Wave garage door accessories.


Z-WAVE DEVICES EDITING Z-WAVE DEVICES

From the Dashboard, you can toggle available devices on and off. You can also select individual devices to access additional commands.

In addition, when you select the Lights, Locks, or Thermostats, you can edit name to use something more descriptive such as Front Door, Upstairs Bedroom, Etc.

Press the icon (

) at top right and it allows you to edit the name of each device.






ADDING Z-WAVE DEVICES


1.) Click on the Z-Wave Menu Icon (

) located on the top right of the home page.

2.) Select Begin Device Inclusion.

3.) Leaving this screen open, walk over to your Z-Wave device and perform the Z-Wave Inclusion process located in the Product Manual of the device. This is typically accomplished by pressing a button on the Z-Wave device.





REMOVING Z-WAVE DEVICES

1.) Click on the Z-Wave Menu Icon (





) located on the top right of the home page.

2.) Select Begin Device Exclusion.

3.) Leaving this screen open, walk over to your Z-Wave device and perform the Z-Wave Exclusion process located in the Product Manual. This is typically simply pressing a button on the board.

When using multiple Gateways on an account, you can choose which Z-Wave device you would like to remove by selecting it from the list or simply press Exclude Other.






REFRESHING Z-WAVE DEVICES

1.) Click on the Z-Wave Menu Icon (



) located on the top right of the home page.

2.) Select Refresh Devices



GETTING HELP

Support for the SecureSmart app, login, and any Z-Wave connected devices will be provided by your alarm dealer.