


IQ GLASS QUICK INSTALL GUIDE



STEP
1

CHOOSE
INSTALLATION
LOCATION

SPECIFICATIONS



Sensor: 4.25" H x 3.13" W x 1.7" D

Sensing parameters: Maximum 25 feet

Mounting Spec: At least 3.3 feet from windows
being protected, and 4 feet from sources of noise

Mounting hardware: #4 or #6 screws

Replacement Battery: CR123A 1550mAh

Temperature Range: 14 °F to 120 °F

Note: Battery Safety

Observe polarity when inserting replacement batteries to avoid damaging the sensor.

Risk of fire, burns and explosion. Do not recharge, disassemble, burn or expose batteries to temperatures above 100°C (212°F)

Dispose of used batteries properly and in accordance with all local laws. Keep batteries away from children.

This is a quick guide for experienced installers only. Refer to <http://dealers.qolsys.com> (login required)


STEP 2

REMOVE
FACE
PLATE




STEP 3

REMOVE
BATTERY
TAB



STEP 4

SECURE
TO
SURFACE



STEP 5

REPLACE
FACE
PLATE



STEP 6

LEARN
INTO
PANEL



Place your panel in
“autolearn” mode



Open and close the case to
“tamper” the device

ADD

Customize name and settings
as desired and touch “ADD”



ASK
JENNI
Qolsys

Document#: IQMDW-QG-03-17
Revision#: 3/22/17
Issue Date: MAR 2017
Qolsys Product #: QS-1410-PO1

Qolsys Inc. proprietary.
Reproduction without permission is not permitted.
FCC ID: U5X-RE109
IC: 8310A-RE109

GOT QUESTIONS?
CONTACT TECH SUPPORT
TechSupport@Qolsys.com

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme avec Industrie Canada exempts de licence standard RSS (s). Son fonctionnement est soumis aux deux conditions suivantes: (1) cet appareil ne doit pas provoquer d'interférences et (2) cet appareil doit accepter toute interférence, y compris celles pouvant causer un mauvais fonctionnement de l'appareil.