


# IQ SMART SOCKET QUICK INSTALL GUIDE




**STEP 1** LOCATE OUTLET NEAR PANEL




**PLEASE NOTE:**  
PAIRING THE IQ SMART SOCKET NEAR THE IQ PANEL IS FOR CONVENIENCE ONLY.

ONCE IQ SMART SOCKET HAS BEEN SUCCESSFULLY PAIRED IT CAN BE MOVED ANYWHERE WITHIN ACCEPTABLE RANGE (APPROX 100 FEET OPEN AIR)

**STEP 2** PLUG INTO OUTLET



**STEP 3** PAIR WITH PANEL






Press button on bottom to "tamper" the device


ADD

Customize name and settings as desired and touch "ADD"


**STEP 4** DECIDE WHAT TO CONTROL




**STEP 5** LOCATE DESIRED OUTLET




**STEP 6** PLUG IN SMART SOCKET



**STEP 7** SECURE INTO PLACE



**STEP 8** PLUG DEVICE IN



Max current 15A or 1800W

## DOCUMENT INFORMATION

Document#: IQSS-QG-03-17  
Revision#: 03222017  
Issue Date: MAR 2017  
Qolsys Part #: QS-2100-P01  
Firmware : 2016\_08\_26\_9D7C

FCC ID: 2AAJXQS2100  
IC: 11205-QS2100  
Qolsys Inc. proprietary.

Reproduction without permission is not permitted.

## SUPPORT

**GOT QUESTIONS?**  
CONTACT TECH SUPPORT  
[TechSupport@Qolsys.com](mailto:TechSupport@Qolsys.com)



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme avec Industrie Canada exempts de licence standard RSS (s). Son fonctionnement est soumis aux deux conditions suivantes: (1) cet appareil ne doit pas provoquer d'interférences et (2) cet appareil doit accepter toute interférence, y compris celles pouvant causer un mauvais fonctionnement de l'appareil.